



Solar Electric NightLight Installation Instructions Appendix




| Parts List | | Quantity |
|------------|--|----------|
| 1 | NightLight Housing Assembly | (1) |
| 2 | Mounting Bracket Assembly | (1) |
| 3 | Rechargeable Battery NIMH AA 1500 mAh 1.2V | (2) |











For Battery Replacement in the Solar Electric Night Light

- 1. Remove Solatube Decorative Fixture and Effect Lens
- 2. Remove Solar Electric NightLight housing assembly by gently lifting the assembly up and off of the mounting bracket. Remove the NightLight assembly from the tube.
- 3. Remove batteries from battery pack.
- Insert batteries to the (+) and (-) marks inside the battery pack.

Warning: Replace with only (x2) NiMH (nickel-metal-hydride) rechargeable batteries (NiMH AA 1500 mAh 1.2V).

Always remove old, weak or worn-out batteries promptly and recycle or dispose of them in accordance with Local and National Regulations



